



1:1
PHASE

SERVOREX SH SERIES

**Full Automatic
STABILIZERS**
from **8 - 20 kVA**



POWER FACTOR



TOWER



EASY
SERVICE



MEDICAL



INDUSTRY



HOME/OFFICE

SERVOREX SH SERIES

Suitable for small offices and home applications.

- Digital Display
- Servo Motor Controlled Technology
- Fast Response for Fluctuations
- Reliable Stabilization for Secure Energy
- High efficiency in each model
- Short circuit protection
- Manual Bypass Switch
- Wide input voltage range version (optional)
- Electro-mechanic (breaker module)
- High-low voltage protection (optional)
- Higher IP applications are available

SERVOREX SH SERIES

MODEL	SRV SH 1108	SRV SH 1110	SRV SH 1115	SRV SH 1120
Power (kVA)	8	10	15	20
Input				
Input Voltage Band Width	165 - 255 VAC / 130 - 240 Vac (Optional)			
Operation Frequency	47 / 65 Hz			
Line Input Protection	Overcurrent, low and high voltage protection, tempature			
Output				
Output Voltage	220 / 230 / 240 VAC RMS $\pm 1\%$			
Overloading	10 Sec. 200% Load			
Correction Speed	~ 90 Volt / Sec.			
Upturn Period	~ 90 Volt / Sec. (160 VAC - 260 Vac)			
Output Protection	Protects load by opening the circuit when overburden, short circuit occurs (Optional)			
Working Principle	Servo motor, Microprocessor controlled, Full automatic			
Environmental				
Working Temperature	-10 °C / 50 °C			
Storage Temperature	-25 °C / 60 °C			
Relative Humidity	<90%, DIN (40040)			
Altitude	<2000 m			
Noise Level (1 meter)	<50 dBA			
Protection Level	IP 20 (Higher IP Ratings are optional)			
Standards	CE / ISO 9001			
Dimensions				
H x W x D (cm)	50 x 30 x 36	55 x 30 x 36	61 x 38 x 41	66 x 40 x 43
Weight (kg)	35	43	72	81

The company reserves the right to change specifications and designs without notice.



INNOVATIVE ENERGY SYSTEMS

www.innovasis.com.tr

The company reserves the right to change specifications and designs without notice.